



Socket	Function	Interface Description			
CN10	12Vin input				
CN6	Fan power socket	1: +12	2: GND		
J1	SATA power socket	1: +5	2: GND	3: GND	4: +12
CN1					
CN2	10PIN without MCU front panel socket	1: +3.3	2: GND	3: IR	4: Y2
		5: Y1	6: X2	7: Y3	8: X1
		9: ALARM	10: REC		
CN4	SATA0				
CN3	SATA1				
J2					
CN5	MCU front panel socket	1: +5	2: GND	3: 5VSB	4: GND
		5: YKIN2	6: NC	7: RXD	8: TXD
		9: PWR_S	10: GND		
BT1	Battery seat				
CN11	Audio expansion seat	1: GND	2: ADUIO_IN4	3: ADUIO_IN3	4: ADUIO_IN2
		5: ADUIO_IN1	6: ADUIO_OUT		
CN9/J6	4ch BNC Video input	Left down: VIDEO4	Left up: VIDEO3	Right down: VIDEO2	Right up: VIDEO1
J4	HDMI				
J5	CVBS interface (only models with CVBS support this				



	interface)				
J3	Audio RCA combination interface	Down :AUDIO_OUT_MAIN	up:AUDIO01		
J7	VGA				
J13	VGA expansion seat	1:GND	2:VS	3:HS	4:RED
		5:GREEN	6:BLUE		
CN7	USB expansion seat	1:+5	2:DM	3:DP	4:GND
CN8	2USB+RJ45				