



sign	Function	Interface Description			
CN1	SATA				
J24	Debug UART	1:RXD	2:TXD	3:GND	
J1	Battery holder				
CN5	10PIN front panel interface 10PIN front panel interface	1:+3.3	2:GND	3:IR	4:COL2
		5:COL1	6:ROW2	7:COL3	8:ROW1
		9:ALARM	10:REC		
J18	Hard disk power socket	1:+5	2:GND	3:GND	4:+12
JT1	12V input				
J23	2*USB				
CN4	USB Extension interface				
J30	RJ45				
J3	HDMI				
J5	VGA				
J9	3.5mm Audio output interface				
CN6	FAN	1:+12	2:GND		