



sign	Function	Interface Description			
J1	Battery holder				
CN2	SATA				
J19	10Pin front panel interface(1.25*10P)	1:+3.3	2:GND	3:IR	4:COL2
		5:COL1	6:ROW2	7:COL3	8:ROW1
		9:ALARM	10:REC		
J16	RS232				
J15	SATA power extension socket	1:+5	2:GND	3:GND	4:+12
CN1	Fan seat	1:+12	2:GND		
CN6	12V input				
J10	2*USB				
CN3	USB Extension interface	1:+5	2:USB_DM	3:USB_DP	4:GND
J6	RJ45				
J12	POE switch expansion interface (compatible)	1:NC	2:NC	3:NC	4:NC
		5:ETHRX-	6:ETHRX+	7:ETHTX-	8:ETHTX+
J7	HDMI				
J8	VGA				
J14	VGA expansion interface (compatible)				

J18	Audio extension socket (compatible)				
J17	3.5mm Audio In/Output interface				