

# **BOMAR**<sup>®</sup>

Operating Instructions for Band Saw

## ***individual 640.520 GANC***




**Before transporting and using the machine, please read  
the instructions thoroughly!**

Serial number:



## Service and Information

In case of technical difficulties or spare parts order, please contact your dealer:



Or contact Bomar, spol. s r.o. directly:

**BOMAR, spol. s r.o.**

Lazaretní 7  
61500 Brno  
CZECH REPUBLIC

Telephone: +420 – 545 152 336  
Telephone: +420 – 545 152 338  
Fax: +420 – 545 152 514

e-mail: [info@bomar.cz](mailto:info@bomar.cz)  
WWW: <http://www.bomar.cz>

We are available Mondays to Fridays from 7<sup>00</sup> to 16<sup>00</sup>.

# Content

|                                                       |           |
|-------------------------------------------------------|-----------|
| <b>1. INTRODUCTION.....</b>                           | <b>7</b>  |
| <b>2. BAND SAW USING .....</b>                        | <b>7</b>  |
| <b>3. TECHNICAL DATA.....</b>                         | <b>8</b>  |
| <b>4. SAFETY NOTES.....</b>                           | <b>9</b>  |
| 4.1. GENERAL .....                                    | 9         |
| 4.2. PROTECTIVE SUIT AND PERSONAL SAFETY .....        | 9         |
| 4.3. SAFETY NOTES FOR MACHINE OPERATOR.....           | 10        |
| 4.4. SAFETY NOTES FOR THE SERVICING AND REPAIRS.....  | 12        |
| 4.5. SAFETY MACHINE ACCESSORIES .....                 | 12        |
| <b>5. TRANSPORTATION AND STOCKING .....</b>           | <b>14</b> |
| 5.1. CONDITIONS FOR TRANSPORTATION AND STOCKING ..... | 14        |
| 5.2. SAFETY NOTES .....                               | 14        |
| 5.3. TRANSPORT AND STOCKING PREPARATIONS .....        | 15        |
| 5.4. TRANSPORT AND STOCKING .....                     | 15        |
| <b>6. ACTIVATION.....</b>                             | <b>16</b> |
| 6.1. MACHINE WORKING CONDITIONS.....                  | 16        |
| 6.2. BAND SAW UNPACKING AND ASSEMBLING .....          | 16        |
| 6.3. MACHINE INSTALLING AND LEVELLING.....            | 17        |
| 6.4. ELECTRICAL CONNECTION .....                      | 18        |
| 6.5. FILLING OF THE COOLING SYSTEM.....               | 19        |
| 6.6. CHECK MACHINE FUNCTIONS.....                     | 20        |
| <b>7. CONTROL PANEL – DESCRIPTION.....</b>            | <b>21</b> |
| <b>8. STARTING THE BAND SAW .....</b>                 | <b>24</b> |
| 8.1. SWITCH ON THE BAND SAW .....                     | 24        |
| 8.2. FEEDER REFERENCE POSITION .....                  | 24        |
| <b>9. MATERIAL INSERTION.....</b>                     | <b>25</b> |
| 9.1. SAFETY NOTES .....                               | 25        |
| 9.2. HANDLING AGENT SELECTION.....                    | 25        |
| 9.3. MATERIAL INSERTION.....                          | 25        |
| 9.4. BUNDLE MATERIAL CUTTING .....                    | 26        |
| <b>10. BAND SAW ADJUSTING.....</b>                    | <b>27</b> |
| 10.1. SAFETY NOTES .....                              | 27        |
| 10.2. ANGULAR CUT SETTING .....                       | 27        |
| 10.3. CUTTING SPEED ADJUSTMENT .....                  | 28        |
| 10.4. OPTIMAL ADJUSTING OF THE GUIDE CUBES SPAN ..... | 29        |
| 10.5. SWARF CONVEYOR OPERATION .....                  | 29        |
| 10.6. PRESSURE ADJUSTING TO THE CUT .....             | 30        |
| <b>11. SEMI-AUTOMATIC CYCLE.....</b>                  | <b>31</b> |
| 11.1. SAFETY NOTES .....                              | 31        |
| 11.2. SEMI-AUTOMATIC MODE.....                        | 31        |
| 11.3. CYCLE BREAKING .....                            | 32        |

|            |                                                        |           |
|------------|--------------------------------------------------------|-----------|
| 11.4.      | SPEED ADJUSTING OF THE ARM LOWERING .....              | 32        |
| <b>12.</b> | <b>AUTOMATIC MODE .....</b>                            | <b>33</b> |
| 12.1.      | SAFETY NOTES .....                                     | 33        |
| 12.2.      | CYCLE PRESET .....                                     | 33        |
| 12.2.1.    | <i>Preset</i> .....                                    | 33        |
| 12.2.2.    | <i>Program storing</i> .....                           | 34        |
| 12.2.3.    | <i>Program selection</i> .....                         | 34        |
| 12.2.4.    | <i>Editing</i> .....                                   | 35        |
| 12.2.5.    | <i>New Preselection inserting</i> .....                | 36        |
| 12.2.6.    | <i>Clearing memory</i> .....                           | 37        |
| 12.3.      | AUTOMATIC CYCLE WITH MATERIAL CUTTING .....            | 38        |
| 12.4.      | AUTOMATIC CYCLE WITHOUT MATERIAL CUTTING.....          | 38        |
| 12.5.      | CYCLE BREAKING .....                                   | 39        |
| 12.6.      | SETTING THE SPEED OF THE SAW ARM LOWERING .....        | 39        |
| <b>13.</b> | <b>BLANKS REMOVING FROM THE BAND SAW.....</b>          | <b>40</b> |
| 13.1.      | SAFETY NOTES .....                                     | 40        |
| 13.2.      | HANDLING AGENT SELECTION.....                          | 40        |
| 13.3.      | BLANKS REMOVING .....                                  | 40        |
| <b>14.</b> | <b>SERVICE MENU.....</b>                               | <b>41</b> |
| 14.1.      | ENTRANCE TO SERVICE MENU .....                         | 41        |
| 14.2.      | VICE PARAMETERS .....                                  | 41        |
| 14.3.      | COOLING PARAMETERS .....                               | 41        |
| 14.3.1.    | <i>Cooling type</i> .....                              | 41        |
| 14.3.2.    | <i>Cooling mode</i> .....                              | 42        |
| 14.4.      | CUTTING PARAMETERS.....                                | 42        |
| 14.5.      | SWARF CONVEYOR OPERATION .....                         | 43        |
| 14.6.      | MACHINE PARAMETERS .....                               | 43        |
| 14.7.      | LANGUAGE .....                                         | 44        |
| 14.8.      | LENGTH UNITS SELECTION .....                           | 44        |
| 14.9.      | REGULATOR .....                                        | 44        |
| 14.10.     | LENGTH CORRECT .....                                   | 44        |
| 14.11.     | SERVICE MENU CLOSING .....                             | 45        |
| <b>15.</b> | <b>SELECTION AND REPLACEMENT OF THE SAW BAND .....</b> | <b>46</b> |
| 15.1.      | SAFETY NOTES .....                                     | 46        |
| 15.2.      | SAW BAND SIZES .....                                   | 46        |
| 15.3.      | SELECTION OF THE SAW BAND TOOTH SYSTEM:.....           | 46        |
| 15.4.      | SAW BAND RUNNING - IN.....                             | 48        |
| 15.5.      | SAW BAND DISMANTLING .....                             | 49        |
| 15.6.      | SAW BAND INSTALLATION .....                            | 50        |
| 15.7.      | SAW BAND STRETCHING AND INSPECTION .....               | 51        |
| 15.7.1.    | <i>Saw band stretching</i> .....                       | 51        |
| 15.7.2.    | <i>Saw band inspection</i> .....                       | 51        |
| <b>16.</b> | <b>COOLING AGENTS AND CHIPS DISPOSAL .....</b>         | <b>52</b> |
| 16.1.      | SAFETY NOTES .....                                     | 52        |
| 16.2.      | COOLING LIQUID PREPARATION .....                       | 52        |
| 16.3.      | COOLANT DEVICE INSPECTION.....                         | 54        |
| 16.4.      | CHIPS DISPOSAL .....                                   | 54        |
| <b>17.</b> | <b>GREASES AND OILS.....</b>                           | <b>55</b> |

|            |                                                                                                                                                           |            |
|------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|------------|
| 17.1.      | GEARBOX OILS .....                                                                                                                                        | 55         |
| 17.2.      | HYDRAULIC OILS .....                                                                                                                                      | 56         |
| 17.3.      | LUBRICANT GREASES .....                                                                                                                                   | 57         |
| <b>18.</b> | <b>SERVICE .....</b>                                                                                                                                      | <b>58</b>  |
| 18.1.      | MACHINE CLEANING .....                                                                                                                                    | 58         |
| 18.2.      | LUBRICATION .....                                                                                                                                         | 58         |
| 18.2.1.    | Clutch of the roller feeder .....                                                                                                                         | 58         |
| 18.3.      | COOLING LIQUID INSPECTION .....                                                                                                                           | 59         |
| 18.4.      | HYDRAULIC OIL LEVEL CHECK .....                                                                                                                           | 60         |
| <b>19.</b> | <b>SERVICING AND ADJUSTMENT .....</b>                                                                                                                     | <b>61</b>  |
| 19.1.      | HARD METAL GUIDES ADJUSTMENT .....                                                                                                                        | 61         |
| 19.2.      | GUIDE CUBES ADJUSTMENT .....                                                                                                                              | 61         |
| 19.3.      | SAW BAND RUN ADJUSTMENT ON STRETCHING WHEEL .....                                                                                                         | 61         |
| 19.4.      | BRUSH ADJUSTMENT .....                                                                                                                                    | 62         |
| 19.5.      | LIMIT SWITCH SETTING OF THE SAW BAND STRETCHING .....                                                                                                     | 62         |
| 19.6.      | LIMIT SWITCH OF THE SAW FRAME LOWER POSITION ADJUSTMENT .....                                                                                             | 63         |
| 19.7.      | ADJUSTMENT OF A THROTTLE VALVE .....                                                                                                                      | 64         |
| <b>20.</b> | <b>WORN PIECES REPLACEMENT .....</b>                                                                                                                      | <b>65</b>  |
| 20.1.      | PUSHING BEARING REPLACEMENT .....                                                                                                                         | 65         |
| 20.2.      | SAW BAND GUIDING PULLEYS REPLACEMENT .....                                                                                                                | 67         |
| 20.3.      | HARD METAL GUIDES REPLACEMENT .....                                                                                                                       | 69         |
| 20.4.      | ROUND BRUSH REPLACEMENT .....                                                                                                                             | 70         |
| <b>21.</b> | <b>ROZMĚROVÉ SCHÉMA / AUFSTELLZEICHNUNG / INSTALLATION DIAGRAM .....</b>                                                                                  | <b>71</b>  |
| <b>22.</b> | <b>ELEKTRICKÁ SCHÉMATA / ELEKTROSCHEMAS / WIRING DIAGRAMS .....</b>                                                                                       | <b>72</b>  |
| <b>23.</b> | <b>HYDRAULICKÉ SCHÉMA / HYDRAULIKSCHEMA / HYDRAULIC DIAGRAM .....</b>                                                                                     | <b>86</b>  |
| <b>24.</b> | <b>VÝKRESY SESTAV PRO OBJEDNÁNÍ NÁHRADNÍCH DÍLŮ / ZEICHNUNGEN FÜR<br/>BESTELLUNG DER ERSATZTEILE / DRAWING ASSEMBLIES FOR SPARE PARTS ORDER<br/>.....</b> | <b>89</b>  |
| 24.1.      | HLAVNÍ SVĚRÁK / HAUPTSCHRAUBSTOCK / MAIN VICE .....                                                                                                       | 90         |
| 24.2.      | PODÁVACÍ SVĚRÁK / VORSCHUBSCHRAUBSTOCK / FEEDING VICE .....                                                                                               | 94         |
| 24.3.      | NAPÍNÁNÍ PILOVÉHO PÁSU / SÄGEBANDSPANNUNG / SAW BAND STRETCHING .....                                                                                     | 97         |
| 24.4.      | OTOČNÁ KONZOLA / DREHKONSOLE / TURNING CONSOLE .....                                                                                                      | 99         |
| 24.5.      | PILOVÉ RAMENO / SÄGERAHMEN / SAW ARM .....                                                                                                                | 101        |
| 24.6.      | ZVEDACÍ VÁLEC / HUBZYLINDER / LIFTING CYLINDER .....                                                                                                      | 103        |
| 24.7.      | CHLAZENÍ / KÜHLUNG / COOLING .....                                                                                                                        | 105        |
| 24.8.      | PODSTAVEC / UNTERGESTELL / PEDESTAL .....                                                                                                                 | 107        |
| 24.9.      | VÁLEČKOVÁ TRAŤ / ROLLENBAHN / ROLLER CONVEYOR .....                                                                                                       | 109        |
| 24.10.     | VÁLEC PODAVAČE / ZYLINDER / FEEDER CYLINDER .....                                                                                                         | 111        |
| 24.11.     | VERTIKÁLNÍ VÁLEČKY / VERTIKAL ROLLEN / VERTICAL ROLLERS .....                                                                                             | 113        |
| <b>25.</b> | <b>TROUBLESHOOTING TABLE .....</b>                                                                                                                        | <b>115</b> |
| <b>26.</b> | <b>ROLLER CONVEYORS AND ACCESSORIES .....</b>                                                                                                             | <b>119</b> |
| 26.1.      | ROLLER CONVEYORS .....                                                                                                                                    | 119        |
| 26.2.      | ROLLER CONVEYORS PREPARED FOR POWERING .....                                                                                                              | 119        |
| 26.3.      | POWER AND CONTROL UNITS FOR POWERED CONVEYORS .....                                                                                                       | 120        |
| 26.4.      | LENGTH STOPS .....                                                                                                                                        | 121        |
| 26.5.      | CONNECTION PARTS .....                                                                                                                                    | 122        |

---

|                                        |                                                                 |            |
|----------------------------------------|-----------------------------------------------------------------|------------|
| 26.6.                                  | CONNECTION SETS .....                                           | 122        |
| 26.7.                                  | ACCESSORIES OF ROLLER CONVEYORS .....                           | 122        |
| 26.8.                                  | COVERS.....                                                     | 123        |
| 26.9.                                  | CONNECTION SCHEMA OF THE ROLLER CONVEYORS TO THE BAND SAW ..... | 124        |
| <b>DECLARATION OF CONFORMITY .....</b> |                                                                 | <b>127</b> |